

Installation Guide

Evolve Rainscreen

A Drainage and Ventilation Mat

Inspection of Wall Conditions and Weather Barrier/Building Wrap

Ensure that the wall is free from structural defects, any membranes or flashing are properly installed, and that the final system will have a path for moisture to escape from the wall. Evolve Rainscreen should only be applied to structurally sound surfaces, which incorporate good building practices, and meet all local code requirements. Before starting any application, check your local building code requirements and read all manufacturers' installation instructions.

Installation Guide for Evolve Stone (USE 1/8" Rainscreen in the USA only and 3/8" in CANADA only)

1. Install Type I or II WRB and flashing according to manufacturers' recommendations.
2. Place Evolve Rainscreen horizontally against exterior wall, fabric side out. The entangled core should face the building interior.
3. Evolve Rainscreen can be installed top/down or down/up when starting out.
4. Seam adjacent Evolve Rainscreen piece with the selvage edge overlapping the top of the lower piece.
5. Mechanically fasten with a cap nail, cap staple, or cap screw; one fastener for each square foot or as necessary to keep the Rainscreen taut. When choosing fastener length, allow for thickness of Evolve Rainscreen.
6. Trim Evolve Rainscreen around all penetrations, windows and doors.